











Directions:

1. Turn to the template on the next page and stick foil tape over the gray lines. 
2. Cover the lonely gray patch with conductive foil. This forms the contact of the switch. 
3. Fold the bottom page corner along the dotted line so that the patch closes the gap. Congrats! You just made a switch. 
4. Crease the top page corner along the dotted line and clip your battery in place with a binder clip (see previous activities for details). 
5. Stick an LED sticker over the footprint. When you press down on the switch, your LED will glow! 
6. Now turn the page. What happens when you press the “do not press” button? Draw it on the page!

This work is licensed under a Creative Commons Attribution-ShareAlike 4.0 International License: <https://creativecommons.org/licenses/by-sa/4.0>

DIY SWITCH 47






Directions:

1. Turn to the template on the next page and stick foil tape over the gray lines. 
2. Cover the lonely gray patch with conductive foil. This forms the contact of the switch. 
3. Fold the bottom page corner along the dotted line so that the patch closes the gap. Congrats! You just made a switch. 
4. Crease the top page corner along the dotted line and clip your battery in place with a binder clip (see previous activities for details). 
5. Stick an LED sticker over the footprint. When you press down on the switch, your LED will glow! 
6. Now turn the page. What happens when you press the “do not press” button? Draw it on the page!

This work is licensed under a Creative Commons Attribution-ShareAlike 4.0 International License: <https://creativecommons.org/licenses/by-sa/4.0>

DIY SWITCH 47






Directions:

1. Turn to the template on the next page and stick foil tape over the gray lines. 
2. Cover the lonely gray patch with conductive foil. This forms the contact of the switch. 
3. Fold the bottom page corner along the dotted line so that the patch closes the gap. Congrats! You just made a switch. 
4. Crease the top page corner along the dotted line and clip your battery in place with a binder clip (see previous activities for details). 
5. Stick an LED sticker over the footprint. When you press down on the switch, your LED will glow! 
6. Now turn the page. What happens when you press the “do not press” button? Draw it on the page!

This work is licensed under a Creative Commons Attribution-ShareAlike 4.0 International License: <https://creativecommons.org/licenses/by-sa/4.0>

DIY SWITCH 47

Directions:

1. Turn to the template on the next page and stick foil tape over the gray lines. 
2. Cover the lonely gray patch with conductive foil. This forms the contact of the switch. 
3. Fold the bottom page corner along the dotted line so that the patch closes the gap. Congrats! You just made a switch. 
4. Crease the top page corner along the dotted line and clip your battery in place with a binder clip (see previous activities for details). 
5. Stick an LED sticker over the footprint. When you press down on the switch, your LED will glow! 
6. Now turn the page. What happens when you press the “do not press” button? Draw it on the page!

This work is licensed under a Creative Commons Attribution-ShareAlike 4.0 International License: <https://creativecommons.org/licenses/by-sa/4.0>

DIY SWITCH 47